

## **Jbm - 54288 - KIT DE CALADO PSA 1.2 GDI PURETECH**

Kit de calado para Citroen, Peugeot y Toyota

Herramientas OEM

Citroen: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Peugeot: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Herramientas OEM

Citroen: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Peugeot: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Vauxhall: EN-52127-2

Códigos de motor

1.2 VTi: 1PP(HM01), EB2 (HMZ), EB2DTS(HNY), EB2 (HMW), EB2M (HMY),  
EB2 (HMZ), EB2DTS(HNY), HMP (EB2FB), HMT(EB2D), HMU(EB2D),  
HMY (EB2M), HMY (EB2M), HMZ (EB2), HMZ (EB2D), HMZ (EB2F),  
HMZ (EB2FB)

1.2 E-VTi: HMZ (EB2F), EB2F (HMZ)

1.2 PureTech THP: HNZ (EB2DT)

1.2 PureTech VTi: EB2ADS (HNS), EB2D(HMT), EB2ADJ (HNP),  
EB2ADT (HNK), EB2ADTX (HNN), EB2DTS (HNW), EB2DTM (HNV),  
EB2DTSM (HNW), EB2FA (HMR), EB2FAD (HMH), EB2FAD (HMM),  
EB2DT (HNZ), EB2F (HMX), EB2F (HMT), EB2F(HMZ), EB2DTS(HNY),  
EB2M(HMY)

Marcas

Citroen: Berlingo IV (18-20), C1 II (14-18), C3 III (12-17), C3 IV (16-18),

C4 Cactus (14-20), C4 Aircross (18-20), C-Elysee (12-18), DS3 (12-18)

Peugeot: 108 (14-18), 208 (12-21), 2008 (13-21), 301 (12-20), 308 (13-21), 3008 (16-21),

508 (19-21), 5008 (14-21), Partner III (15-18) Partner IV (18-21) Rifter (19-21)

Toyota: Aygo (14-18)

GM: Crossland X (17-20), Combo E (18-20), Grandland X (17-20)

