

SODISE - 71521 - KIT DE CALADO PARA VAG 1.6D TDI CR, 2.0D TDI CR

AUDI: A3 1996-2009, A4 1994-2009, A6 1995-2011, S3 1999-2013, TT 1998-2014.

SEAT: ALHAMBRA 1997-2010, ALTEA/ALTEA XL 2006-2009, CORDOBA 1999-2002, EXEO 2009-2010, IBIZA 1999-2002, LEON 1999-2013, TOLEDO 1999-2009.

SKODA: OCTAVIA/OCTAVIA TOUR 1998-2010, OCTAVIA II 2004-2009.

VW: BEETLE 1999-2011, BORA 1997-2004, EOS 2006-2010, GOLF 1997-2012, GOLF PLUS 2005-2009, JETTA 2005-2009, PASSAT 1996-2010, SCIROCCO 2009-2014, SHARAN 1997-2010, TOURAN 2003-2009.

Codes moteurs : AWA, AXW, AXX, BGB, BHD, BHZ, BLR, BLX, BLY, BMB, BPG, BPJ, BPY, BUL, BVX, BVY, BVZ, BWA, BWE, BWJ, BWT, BYD, BYK, BZC, CDLA, CDLB, CDLC, CDLD, CDLF, CDLG, CDLJ, CDLK, CDMA.

