

Jbm - 53277 - SET HERRAMIENTAS PARA CORREA DISTRIBUCIÓN

Aplicaciones (DIESEL):

Audi: 80, 100, A3, A4, A6 1.9 Turbo D, 1.9TDi, 2.5TDi, A3, A4, A6 2.0TDi, A2, A3, A4, A6 1.2TDi, 1.4TDi, 1.9TDi (99-)

Ford: Galaxy 1.9TD

Seat: Ibiza/Cordoba, Leon, Toledo, Alhambra, Inca 1.7SDi, 1.9D/TD/Sdi/Tdi

Skoda: Felicia, Octavia 1.9D/Tdi

VW: Polo, Polo Classic, Golf, Jetta, Vento, Bora, Beetle, Passat, Sharan, Caddy, Transporter 1.5D, 1.6D/Turbo, 1.7D/Sdi, 1.9Sdi/Tdi, Golf, Passat 2.0TDi

Aplicaciones (GASOLINA):

Audi: 80, 100, A3, A4, A6 1.6, 1.8/Turbo, 2.0, 2.0 16v, A3, A4 1.6 (96-)

Seat: Ibiza/Cordoba, Toledo, Alhambra, Inca 1.6, 1.8, 1.8 16v, 2.0, 2.0 16v, Ibiza/Cordoba, Leon, Toledo 1.6 (99-), Alhambra 2.0 (00-)

Skoda: Octavia 1.6 (97-), 2.0 (99-)

VW: Polo Classic, Scirocco, Corrado, Golf, Jetta, Vento, Passat, Sharan, Transporter 1.6, 1.8/Turbo, 1.8 16v, 2.0, 2.0 16v, Polo Classic, Golf, Bora, Beetle 1.6 (97-), 2.0 (99-)

